

Automatic (Default Settings)

The default speeds are 2830/2430/2000 rpm on High (3), Medium (2), and Low (1), respectively.

No 3 – High (2850) = 100% of the motor power capacity.

No 2 – Medium (2400) = 80% of the motor power capacity.

No 1 – Low (2000) = 60% of the motor power capacity.

When starting the pump, the unit will begin "priming" on high for 5 minutes. The priming speed is at 2850rpms. When completed, it will automatically default to the predetermined speed setting. The pump will immediately stop when the "0" button is pressed and can be restarted with any of the speed buttons.